

INSTRUCTIONS: Line Volt Pendant Light

- **CAUTION:** Always turn off power at fuse box prior to installation to prevent electrical shock.
- Do not install in damp or wet locations.

To Mount Canopy:

1. Order of components is shown in the exploded diagram on the right.
2. Fasten the cross bar to the junction box with the screws provided. The knot in the wire will rest against the crossbar.
3. Connect white wire to the white wire from the junction box, connect the two black wires with wire nuts. Connect the ground wire from the junction box (may be green or an uninsulated wire) to the green wire from the fixture, with a wire nut. Tuck wires into the junction box.
4. Position the male end of the cord fitter through the canopy. Slide the canopy up so it is snug against the ceiling and thread the female fitter piece from below.

To Field Shorten Pendant:

1. Undo the socket assembly by turning the retaining ring counter clockwise. Unscrew the socket in the same direction.
2. Gently pull the wires from the socket and undo the wire nuts. Loosen the strain relief bushing and slide up the length of wire as needed.
3. Tighten the strain relief bushing, trim wires to correct length and reconnect, be sure to use the same ceramic wire nuts provided.
4. Reinstall the socket.

To Install Shade:

1. Remove retaining ring from the socket by turning it counter-clockwise.
2. Slip the shade over the socket and replace the retaining ring.
3. Turn the retaining ring clockwise until the shade is snug fit to the aluminum cone.

Suitable Bulbs			
Type	Base	Voltage	Max Watts
A lamp	E27	120	150
G lamp	E27	120	150

